
SGA-510 Spray Gun



| Ref. No. | Replacement Part No. | Description | Qty. | Ref. No. | Replacement Part No. | Description | Qty. |
|---------------------------|--|---|------------------|------------------------------|---|--|-------------|
| 1 2 3 * 4 * 5 | 3 SGA-56 4 SGA-58-K5 | Retaining Ring (See Note) Air Cap Fluid Tip Fluid Tip Gasket | . 1 1 1 | 12 13 *14 15 | SGB-16-K3 SGB-14 SGB-15-K5 SGB-13-K3 | Retaining Nut Fluid Needle Adjusting Screw Fluid Needle Packing Packing Retainer | 1 1 1 |
| 6 * 7 * 8 | SGA-426 SS-2666-K5 SGB-408 SGB-32-2-K10 | "O" Ring Horn Air Valve Assembly "O" Ring Valve Stem & Gasket Assembly Air Valve Spring | 2 1 1 1 | *16 *17 18 19 20 | SST-8416 SGA-16 SGA-27 P-TGA-29 SGD-2 | Snap Ring Stud Trigger Nipple Locknut | 2 1 1 |
| 10 11 | SGA-425 CGA-40-K5 | Needle Assembly Spring | 1 | 21 | SGD-1 | Fluid Adapter | 1 1 |

Suffixes -K3, -K5, -K10 designate kits of multiple parts. Example: SGA-58-K5 is a kit of five gaskets.

Note: Retaining ring (1) is unique to the SGA-510 gun. No other retaining ring of DeVilbiss manufacture will fit this gun properly.

*A sufficient quantity of parts is included in repair kit KK-4357 for complete gun repair.

FOR PARTS PURCHASE

Contact your local distributor. See the "Yellow Pages" of your telephone directory.

SPECIFICATIONS

Fluid Inlet 3/8 NPS(M)

SERVICE NOTES

For guide on air spray gun maintenance, see Service Bulletin SB-F-2-001.

For complete guide on air spray gun, order free Service Bulletin SB-2-001.

Strain material thru 60 or 90 mesh screen.

To clean fluid passages, remove excess material at source, then flush with a suitable solvent. Wipe exterior with a solvent soaked cloth.

To clean air cap, use a stiff bristle brush. If necessary, use a broom straw or toothpick. Never use a wire or hard instrument. This may scratch or burr holes causing a distorted spray pattern.


After each days use, place a drop of oil on trigger stud (17) and shank of fluid needle (10) where it enters packing retainer (15). Fluid needle packing (14) should be kept soft and pliable by periodic lubrication. Fluid needle spring (11), should be kept coated with a light grease.


If fluid inlet (21) is removed for any reason, lubricate threads with light grease before reassembly.


CAUTION


The Air Valve Assembly (6) is under pressure whenever the gun is triggered. If this valve is turned out too far, it may leave the gun forcefully when the gun is triggered. Also, the "O" ring (5) may be damaged if the valve is turned out past the first thread. Do not turn the valve past the first thread - there will be no effect on the spray pattern after that position.

ACCESSORIES









HLF-501 FILTER/REGULATOR

Combination air filter and regulator for general utility. Capacity, 40 cfm.

Max inlet pressure, 250 psi.

Max regulated outlet pressure, 125 psi.

Inlet connection, 1/4 npt (F).

Outlet connection, 1/4 nps (M).

HA-2125 and HA-2150 AIR HOSE ASSEMBLY

Air supply hose available in 25 and 50 foot lengths. Hose connections are reusable.

DISTRIBUTION CENTERS

DeVilbiss has authorized distributors throughout the world. For Equipment, parts and service, check the yellow pages under "Spray Equipment" and "Com-

Distribution Center ATLANTA, GA 30336

*CLEVELAND, OH 44142 *ELMHURST (Chicago), IL 60126 IRVING (Dalias), TX 75038 NORWALK (Los Angeles), CA 90650 PISCATAWAY, NJ 08854

*SAN JOSE, CA 95112

520 Wharton Circle, P.O. Box 43226, Industrial Branch 15401 Commerce Park Drive 747 Church Rd. Bldg. G-12A 1520 Walnut Hill Lane 13547 Pumice Street 45 Colonial Road, P.O. Box 399 1445 Koll Circle, Suite 111

pressors." If further assistance is required, write or call one of the following DeVilbiss Distribution Centers or Sales Offices nearest you.

> Telephone No. (404) 696-4940 (216) 267-6525 (312) 833-5850 (214) 252-8581 (213) 921-6114 (201) 981-0171 (408) 288-8780

*Sales Office Only

THE DEVILBISS COMPANY TOLEDO, OHIO 43692