The GFC-501 cup lid is designed to be dis-

## Chart 1 – Air Caps

Air Cap (Ref		
Part No.	Computer No.	Application
FLG-1-1	690000	Conventional
FLG-1-3	690001	HVLP

stem of the air valve (15). The shank of the fluid needle (12) where it enters the packing nut (25) should also be oiled. The fluid needle packing (24) should be kept soft and pliable by periodic lubrication. Make sure the baffle (6) and retaining ring (1) threads are clean and free of foreign matter. Before assembling retaining ring to baffle, clean the

threads thoroughly, then add two drops of

buily, apply a alop of ool to spray guil

lube at trigger bearing stud (22) and the

or 2) remove fluid needle adjusting screw (14) to relieve spring pressure against needle collar.

tigritering or roosering the naid tip

19

23

## Chart 2 – Fluid Tips

Fluid Tip (Ref. No. 5) Fluid Tip		Fluid Tip				
	Computer	Size	Size			
Part No.	No.	(in.)	(mm)	Applications		
FLG-332-13K	803051	0.051	1.3	Stains, lacquers, basecoats, clears.		
FLG-332-15K	803052	0.059	1.5	General purpose, light to medium viscosity material.		
FLG-332-18K	803053	0.070	1.8	Primers and medium viscosity materials.		
FLG-332-22K	803054	0.086	2.2	Latex and heavy materials.		

## Chart 3 – HVLP Air Flows (#3 Cap)


(#3 Oap)						
Inlet Press. (PSI)	Air Flow (SCFM)	Cap Press. (PSI)				
15	10	6				

11.5


13

8

10



Ref.	Computer Part No.	Replacement Part No.	Description	Ind. Parts
			Description	Required
1	803055	FLG-333	Retaining Ring	1
2			Air Cap	1
3			Fluid Tip	1
*4		FLG-304-K5	Fluid Tip Seal (Kit of 5)	1
	5 See Chart 2		Fluid Tip & Seal Kit	
6	690021	FLG-305	Baffle	1
7	192151	KGP-13-K5	Cup Gasket Kit (Kit of 5)	1
8	803056	FLG-334	Spreader Adjustment Valve	1
*9			Seal	1
10			Bushing	1
11	803057	FLG-491	Seal, Bushing, Spring & Knob Kit	
12	690023	FLG-311	Fluid Needle	1
*13			Needle Spring	1
14			Needle Adjusting Knob	1
*15			Air Valve	1
*16			Air Valve Spring	1
17			Air Valve Cap	1
18	803058	FLG-492	Air Valve Kit	
19	690026	FLG-322	Air Inlet Fitting	1
*20			Trigger Screw	1
21			Trigger	1
*22			Trigger Stud	1
23	690029	FLG-485	Trigger, Stud & Screw Kit	
*24			Needle Packing	1
25			Needle Packing Nut	1
26	690028	FLG-484	Needle Packing & Nut Kit	
			(3 Packings & 1 Nut)	
27	120175	GFC-502	Metal Gravity Feed Cup	1
	190252	GFC-501	Delrin Gravity Feed Cup	1
28	190944	GFC-404-K2	Disposable Lid Kit (Kit of 2)	1
			(for GFC-502)	
	190225	GFC-402	Lid Kit (for GFC-501)	1
29	190181	KGP-5-K5	Filter Kit (Kit of 5)	1 1



<sup>\*</sup> A quantity of necessary parts is included in Repair Kit FLG-488 (Computer No. 690031) for complete gun repair and should be kept on hand for service convenience.